LM 4200-DK *Hardware layout*



1	Handle LM
2	Bottom hinge
3	Countersunk screw M5 x 8.5
4	Bottom hinge pin
5	Corner hinge
6	Clamping piece E
7	Retainer
8	Top hinge pin
9	Top hinge
10	Stay hinge
11	Countersunk screw M5 x 7
12	Bottom hinge SV right/left
13	Corner hinge right/left
14	Top hinge pin A0026
15	Top hinge
16	Stay hinge
17	Countersunk screw M5 x 7
18	Countersunk screw M5 x 13
19	Supporting piece
20	Stay LM 4200
21	Locking bolt DK
22	Clamping piece EUL
23.1	Corner drive VSO
23.2	Striker
24.1	Tilt lock 10 mm
24.2	Striker E 10 mm
25	Run-up block
26	Tilt locking part
27	Handle LM
28	Bottom hinge
29	Coupling bracket LM
30	Cheese head screw M5 x 12
31	Cheese head screw M5 x 12
32	Mishandling device LM
33	Coupling bracket LM
34	Striker
35	Slider
36	Corner drive VSU/BSO
37	Eccentric rivet
38	Locking cam
39	Additional stay
40	Striker plate
41	Handle support LM
42	Pressure piece SV
43	Pressure piece AV

All text passages marked with ">" are for sash width and sash height ≥ 1,250 mm.

Preparation

A Make punch out for handle LM (**1**).
B Open the operating rod guiding groove.
C Remove the rebate seal in the area through which the hinges pass and rework the sash profile according to the specifications on page 6.
D Rework operating rods S1 - S5 according to the specifications on page 6.
> E Install eccentric rivet (**37**) and locking cam (**38**) on S3 as shown (see page 2).

Sash

> A Insert slider (page 2: **35**) with operating rod S4 and corner drive VSU/BSO (**36**) vertically on the BSO.
B Insert slider DK (**21**), stay LM 4200 (**20**) and operating rod S3 horizontally on the VSO.
> C Insert locking bolt DK (**21**), stay LM 4200 (**20**), operating rod S3 and striker plate (**40**) horizontally on the VSO.
> D Couple locking bolt DK (**21**) with corner drive VSU/BSO (**36**). Make sure positioning of the coupling piece for corner drive VSU/BSO (**36**) is correct.
E Attach stay hinge (**10/16**) and stay LM 4200 (**20**) using countersunk screw M5 x 7 (**11/17**) (torque 2.5 ± 0.25 Nm).
F Position stay hinge (**10/16**) according to specifications on page 4 and fasten stay LM 4200 (**20**) with punching screws.
> G Insert slider (**35**) with operating rod S5 and corner drive VSU/BSO (**36**) vertically on the VSU.
H Insert tilt lock 10 mm (**25**), operating rod S1, coupling bracket LM (**29/33**), operating rod S2 and corner drive VSO (**23.1/23.2**) vertically on the VSO.
> I Couple tilt lock 10 mm (**25**) with corner drive VSU/BSO (**36**). Make sure positioning of coupling piece for corner drive VSU/BSO (**36**) is correct (Figure 1).
J Couple corner drive VSO (**23.1/23.2**) with operating rod S3 "**>**striking plate (**40**)" and secure with clamping piece EUL (**22**).
K Insert run-up block (**27**) horizontally on the VSU.
FBS-EUL ***L*** Attach handle LM (**1**) with cheese head screws M5 x 12 (**30**) (torque 2.5 ± 0.25 Nm). Make sure the handle catch closes into the coupling bracket LM (**29**).
FBS-G ***L*** Attach mishandling device LM on rebate (**32**) with cheese head screws M5 x 12 (**31**) to handle LM (**1**) (torque 2.5 ± 0.25 Nm). Make sure the handle catch closes into the coupling bracket LM (**33**).
BS LM 4200 ***L*** Press bottom hinge pin (**4**) into corner hinge (**5**) DIN right or DIN left.
BS LM 4200 ***M*** Insert clamping piece E (**6**) vertically on the BSU and attach corner hinge (**5**) using countersunk screws M5 x 8.5 (**3**) (torque 2.5 ± 0.25 Nm).
BS LM 4200/SV ***N*** Insert corner hinge right/left (**13**) into the sash groove and fasten with the pre-installed countersunk screws M5 x 8.5 (torque 2.5 ± 0.25 Nm).



Figure 1

Frame

A For sashes weighing *more than 100 kg*, fasten the supporting piece (**19**) to the frame using countersunk screws M5 x 13 (**18**) (torque 2.5 ± 0.25 Nm) (see page 7).
BS LM 4200 ***B*** Position bottom hinge (**2**) and top hinge (**9**) and fix both in place by tightening the cheese head screws (torque 2.5 ± 0.25 Nm).
BS LM 4200/SV ***B*** Position bottom hinge SV right/left (**12**) and top hinge (**15**) and fix both in place by tightening the cheese head screws (torque 2.5 ± 0.25 Nm).
C Connect top hinge pin (**8**) with retainer (**7**) and insert into the top hinge (**9**) from underneath.
BS LM 4200 ***C*** Insert top hinge pin A0026 (**14**) into top hinge (**15**) from below.
BS LM 4200/SV ***D*** Position striker EUL-FBS (**24.1**)/striker (**24.2**), striker E 10 mm (**26**) and tilt locking part (**28**) according to specifications on page 7 and fix each in place using grub screws (torque 1.5 ± 0.25 Nm).
> E Position strikers (**34**) on the BS and VS according to specifications on page 7 and fix each in place with grub screws (torque 1.5 ± 0.25 Nm).
> F Position strikers (**34**) on the VSU and VSO according to specifications on page 7 and fix each in place with grub screws (torque 1.5 ± 0.25 Nm).
> G For sash widths from 1,251 mm to 1,600 mm and/or sash weights in excess of 100 kg (sash width min. 1,020 mm), use additional stay LM 4200 (**39**) and position according to specifications on page 7 (torque 2.5 ± 0.25 Nm).

Final installation

A Hinge the sash. Push top hinge pin (**8/14**) through and snap into place.
B Top hinge pin (**8/14**) **must** be secured in the stay hinge (**10/16**) with a grub screw (torque 2.5 ± 0.25 Nm) (see Figure 2).
C Check that the window works correctly.



Figure 2

Making adjustments

	A	Width adjustment:	
		continuous	using stay LM 4200 (**20**) +2 mm / - 3 mm
BS LM 4200			using pressure piece SV (**42**) ±0.8 mm
BS LM 4200/SV		continuous	using bottom hinge SV right/left (**12**) ±1 mm (make adjustment after glazing, under load and with the sash **open**)
BS LM 4200	***B***	Height adjustment:	after removal of the top pressure piece from the bottom hinge (**2**)
BS LM 4200			using 4 mm hexagon socket screw in corner hinge (**5**) +1.5 / - 1 mm for FH ≤ 1,600 mm in tilt position, for FH ≥ 1,600 mm in turn position
BS LM 4200/SV			using 4 mm hexagon socket screw in corner hinge right/left (**13**) +2 / -1 mm
	C	Pressure adjustment:	using eccentric locking cam
BS LM 4200			pressure piece AV (**43**) ±0.5 mm

Nederlandse vertaling

Siegenia - Nederlandse vertaling

Bron: Siegenia ALU-planningshandboek LM 5200 / LM 4200 / axxent (Engels), Duits, blz. 123, 126. Vertaling Kozijn Parts.

Dit artikel: 256367 (in de bladen hiervoor geel gemarkeerd)

Siegenia handboek blz. 123 - LM 4200-DK Hardware layout (LMen1362 blz. 2)

24.1 Tilt lock 10 mm / 24.2 Striker E 10 mm	24.1 kiepvergrendeling met nok 10 mm / 24.2 sluitstuk E 10 mm
25 Run-up block / 26 Tilt locking part	25 oploopblok / 26 kiepsluitstuk (tegenstuk op het kozijn)
29 Coupling bracket LM / 30, 31 Cheese head screw M5 x 12 / 32 Mishandling device LM / 33 Coupling bracket LM	29 koppelbeugel / 30, 31 cilinderschroef M5 x 12 / 32 anti-foutbediening LM / 33 koppelbeugel
1 Handle LM / 20 Stay LM 4200 / 23.1 Corner drive VSO / 34 Striker / 36 Corner drive VSU/BSO	1 kruk / 20 schaar / 23.1 hoekoverbrenger sluitzijde boven / 34 sluitstuk / 36 hoekoverbrenger

Siegenia handboek blz. 126 - LM 4200-DK Assembly instructions (LMen1362 blz. 5)

H Insert tilt lock 10 mm, operating rod S1, coupling bracket LM, operating rod S2 and corner drive VSO vertically on the VSO	H kiepvergrendeling 10 mm, stang S1, koppelbeugel, stang S2 en hoekoverbrenger verticaal aan de sluitkant aanbrengen
K Insert run-up block horizontally on the VSU	K oploopblok liggend onderaan de sluitkant aanbrengen
L Attach mishandling device LM on rebate with cheese head screws M5 x 12 to handle LM (torque 2.5 Nm). Make sure the handle catch closes into the coupling bracket LM	L anti-foutbediening met cilinderschroeven M5 x 12 samen met de kruk vastzetten (2,5 Nm); de meenemer van de kruk moet in de koppelbeugel grijpen

Vertaling door Kozijn Parts van de originele fabrikantpagina's hiervoor. Bij verschil geldt de originele tekst van de fabrikant.

Klik op een artikelnummer om het artikel op kozijnparts.nl te bekijken. Blauw onderstreept = klikbaar.